

WHAT'S INCLUDED:



EZ Coat



*C-Flex is available in two colors, natural gray or white.

WHAT YOU'LL NEED:



Distilled water



Paddle mixer



Mixing bucket



Mesh strainer bag

Recommended application tools:



*Regular concrete:
18" 3/8" nap roller

*Stamped concrete:
18" 1/2" nap roller



Hopper Gun

*For vertical applications

Step 1

In a 2 gallon bucket, mix the **Primer** with distilled water.
(measurements: 3 part water to 1 part primer)



Step 2

While continuing to mix, slowly pour the **C-Flex** cement into the bucket. Mix well for 4-5 minutes.



Step 3

After mixing, run the **EZ Coat** through a mesh strainer (to rid of any clumps) and into your application tool. (Paint pan, or hopper gun). You are now ready to apply **EZ Coat**.

